



## Motor Box Mounting Diagram

Pedestal, Round Stem

Vertical Motor Box

Reverse (Faces forward)

Clutch Inside Wheel Diameter

### Notes:

- \* Drive pulley pulls outward 1/4"
- \* 1" spacer required for wheel pulley because drive pulley is inside wheel radius
- \* Check that engine levers or other parts do not hit the wheel pulley

\* If the belt is too short, the belt won't make enough contact with the drive pulley gear causing the belt to slip at higher loads.  
Recommended minimum belt distance is 15.25"

\* If the belt is too long, the drive pulley will hit the wheel rim

Wheel Spoke Spacer/Shims  
Note - shims supplied are separate for each spoke, not a ring as shown

Shim

Stainless Reverse Mount Plate

Drive pulley inside wheel radius

